

Glass cleaners

Topcleaner

Topcleaner removes deposits such as dust and grime from inside and outside your greenhouse. Topcleaner has powerful cleaning properties and produces no vapour. The cleaner can be used on glass and film, but not on coated glass.



Cleaned and clear glass or film allows more light to penetrate the greenhouse. This light is important for the growth of crops. It is therefore important to clean the glass or film of the greenhouse regularly. Topcleaner has powerful cleaning properties and produces no vapour. The cleaner can be used on glass and film, but not on coated glass.

Use

The following applies to all our cleaners: after spraying the product, rinse with water within 15 minutes or before it dries. During use wear appropriate personal protection equipment. The cleaners produce a spray when applied. Do not allow any of the cleaning agent or rinse water to end up in a water reservoir or surface water.

Used packaging

You can return Topcleaner packaging after use in the Netherlands and Belgium. For more information, visit **houweling.com/recoservice** or ask us about the conditions.

Packaging

Topcleaner is available in the following packaging sizes:

Topcleaner

•		
Packaging	Article number	Per pallet
Jerrycan 20 litres	T-TOPCLEANER-305	28

Product range

Our product range also includes the glass cleaners Flusol-Forte and Eco-Forte, as well as shading agents, biocides and personal protective equipment. Visit **houweling.com** to see what we have to offer.

For safe keeping

Contact our specialists for personal advice. Always read the instructions on the label before use.